

TAPE FOLDER

Folder folds the tape exactly in the middle, in a quick and easy way.

Part no

1650

How to use the Rutgerson tape folder

1. Loosen the two wing nuts (A). Push the two stainless plates (B) + (C) upwards.

2. Fold/crease half a metre of the tape (D) you want to fold, exactly in the middle.

3. Insert the folded/creased tape into one of the slots. Use the narrow slot for tapes lighter than 280 grams/sqm, and the wider slot for tapes heavier than 280 grams/sqm. The fold should point towards the stainless plate. (If necessary you can feed the tape with a pair of scissors or spike through the slot (E)).

4. Push the stainless plate down against the folded tape. Tighten the wing nuts again.

5. Pull the tape straight through the tapefolder. To make it easier place the folder in a vice or bolt on to a bench either vertically or horizontally, through the holes (F).

